


Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø4.0

Guide Sleeve Offset 11

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Sinus Drill					
Ø2.0	Ø2.7/Ø3.2	Ø3.2	Ø3.2		
16	16	17	18	0.4 ~ 0.8cc	195

Bone Condenser

L 12

Ø3.9

18

OFFSET
11

