

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 11

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0		Ø2.7/Ø3.2		Ø3.2		Sinus Drill		Final Drill		
								Ø3.9	Ø4.3	Ø4.8
16		16		17		18	0.4 ~ 0.8cc	18	18	172

Bone Condenser

L 12

OFFSET
11

