

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 12.5

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0

14

Ø2.7/Ø3.2

14

Sinus Drill

Ø3.2

15 0.4 ~ 0.8cc 16

Bone Condenser

L9

Final Drill

Ø3.9

155

Ø4.3

155

