


Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø4.0

Guide Sleeve Offset 12.5

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0

15

Ø2.7/Ø3.2

15

Sinus Drill

Ø3.2

17

0.4 ~ 0.8cc

18

Bone Condenser

L9

16.0
~
16.4

OFFSET
12.5