

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 9.5

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0		Ø2.7/Ø3.2		Sinus Drill Ø3.2		Bone Condenser		Final Drill	
	12		12						
				13	0.4 ~ 0.8cc	14	L9	155	155

Bone Condenser

L9

Final Drill

Ø3.9 Ø4.3

155 155

OFFSET
9.5

