

# Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 9.5

\*Use proper bone condenser regarding the height.



Ø2.0

Ø2.7/Ø3.2

Sinus Drill

Ø3.2

Final Drill

Ø3.9

Ø4.3

Tissue Punch  
Top Drill

13

13

14

0.4 ~ 0.8cc

15

Bone Condenser

L9

155

155

OFFSET  
9.5

13.5  
~  
13.9