

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 12.5

*Use proper bone condenser regarding the height.



Ø2.0		Ø2.7/Ø3.2		Sinus Drill		Final Drill	
				Ø3.2		Ø3.9	Ø4.3
13		13		15	0.4 ~ 0.8cc	16	

Bone Condenser

L9

155

155

OFFSET
12.5

