

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø4.0

Guide Sleeve Offset 11

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0		Ø2.7/Ø3.2		Ø3.2		Sinus Drill		Final Drill	
16		16		17		195	0.4 ~ 0.8cc	L 12	186

Bone Condenser

L 12

186

OFFSET
11