

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø4.0

Guide Sleeve Offset 11

*Use proper bone condenser regarding the height.



Ø2.0

Ø2.7/Ø3.2

Sinus Drill

Ø3.2

14

14

15

0.4 ~ 0.8cc

16

Bone Condenser

L9

Tissue Punch
Top Drill

