

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø4.0

Guide Sleeve Offset 9.5

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0

12 16

Ø2.7/Ø3.2

12 16

Ø3.2

17

Sinus Drill

Ø3.2

18 0.4 ~ 0.8cc 195

Bone Condenser

L 12

Ø3.9

18

OFFSET
9.5