


Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 11

*Use proper bone condenser regarding the height.



Ø2.0

13

Ø2.7/Ø3.2

13

Sinus Drill

Ø3.2

15

0.4 ~ 0.8cc

16

Bone Condenser

L9

Final Drill

Ø3.9

155

Ø4.3

155

14.0
~
14.4

OFFSET
11