

Pylon Crestal Surgical Guide Drilling Protocol

Implant Ø5.0

Guide Sleeve Offset 11

*Use proper bone condenser regarding the height.



Tissue Punch
Top Drill

Ø2.0

16

Ø2.7/Ø3.2

16

Ø3.2

17

Sinus Drill

Ø3.2

195 0.4 ~ 0.8cc

Bone Condenser

L 12

Final Drill

Ø3.9

186

Ø4.3

186

Ø4.8

187

OFFSET
11